


QUICK REFERENCE SMSB482

Installation

1. Disable PIN CODE from SIM CARD
2. Insert SIM CARD into device (see image)
3. See the next page (Sample Electrical Connection)



Software installation


1. Turn the device OFF.
2. Press and hold the button (▲) and connect USB cable (without the power supply) to the PC.
3. Be sure that a USB mass storage on "Resource Manager" will appear on your PC.
4. Open "Resource Manager" and open the folder of device "SMSB482" ; then double click on "Setup.exe".
5. Disconnect USB cable when finished.

You can find the complete user's guide in Micro-SD Card and also
In the SMSB482 software (click "Help")

Programming SMSB482

1. Turn the device ON with power supply.
2. Connect USB cable to the PC
3. Open SMSB482 Software
4. Insert users (phone numbers and names)
5. Set your functions

SAMPLE ELECTRICAL CONNECTION



Analog Inputs

